














| No. | Product  | Part Number | Description                      | Qty |
|-----|----------|-------------|----------------------------------|-----|
| 1   | FX7221-Z | 5611245001  | SPECIAL SCREW                    | 1   |
| 2   | FX7221-Z | 3660753044  | Compression spring               | 2   |
| 3   | FX7221-Z | 5650710109  | Washer                           | 4   |
| 4   | FX7221-Z | 3706973053  | Fixing plate                     | 5   |
| 5   | FX7221-Z | 5610361156  | Pan head screw                   | 10  |
| 6   | FX7221-Z | 5610361157  | Pan head screw                   | 8   |
| 7   | FX7221-Z | 3135647001  | Left end cap                     | 1   |
| 8   | FX7221-Z | 3135648001  | Right end cap                    | 1   |
| 9   | FX7221-Z | 3708591001  | Rail pointer                     | 1   |
| 10  | FX7221-Z | 5610361192  | Pan head screw                   | 3   |
| 11  | FX7221-Z | 5610361158  | Pan head screw                   | 6   |
| 12  | FX7221-Z | 5650710079  | Plain washer                     | 7   |
| 13  | FX7221-Z | 3709548001  | Kick-back pawl BRACKET           | 1   |
| 14  | FX7221-Z | 5610361193  | Pan head screw                   | 2   |
| 15  | FX7221-Z | 3130253230  | Tube Holder                      | 1   |
| 16  | FX7221-Z | 4600231001  | CUT SENSE                        | 1   |
| 17  | FX7221-Z | 3135650001  | COVER                            | 1   |
| 18  | FX7221-Z | 5610361169  | Pan head screw                   | 16  |
| 19  | FX7221-Z | 5610361175  | Lock screw                       | 2   |
| 20  | FX7221-Z | 3135651001  | CABLE CLIP                       | 1   |
| 21  | FX7221-Z | 3423693001  | UNDERCARRIAGE                    | 1   |
| 22  | FX7221-Z | 2730438001  | MOTOR ASSEMBLY                   | 1   |
| 23  | FX7221-Z | 3130253231  | GUARD PLATE                      | 1   |
| 24  | FX7221-Z | 5610361160  | Pan head screw                   | 1   |
| 25  | FX7221-Z | 5610361161  | Hex screw                        | 1   |
| 26  | FX7221-Z | 3556216001  | RIGHT SLIDING ROD                | 1   |
| 27  | FX7221-Z | 3556217001  | LEFT SLIDING ROD                 | 1   |
| 28  | FX7221-Z | 5650710124  | Spring Lock Washer               | 4   |
| 29  | FX7221-Z | 5610361162  | Hex screw                        | 4   |
| 30  | FX7221-Z | 3580000026  | Bushing                          | 1   |
| 31  | FX7221-Z | 3706973060  | Support plate                    | 1   |
| 32  | FX7221-Z | 5610361164  | Pan head screw                   | 6   |
| 33  | FX7221-Z | 5610361165  | Hex screw                        | 1   |
| 34  | FX7221-Z | 5650710112  | Washer                           | 2   |
| 35  | FX7221-Z | 5610361194  | HEX TEETH SCREW                  | 5   |
| 36  | FX7221-Z | 3709040001  | BRACKET                          | 1   |
| 37  | FX7221-Z | 3580000028  | Bushing                          | 1   |
| 39  | FX7221-Z | 3660753045  | Torsion spring                   | 1   |
| 40  | FX7221-Z | 3709049001  | STOP PLATE                       | 1   |
| 41  | FX7221-Z | 5610361166  | Special screw                    | 2   |
| 42  | FX7221-Z | 3130253256  | GUARD PLATE                      | 1   |
| 43  | FX7221-Z | 5610361167  | Pan head screw                   | 2   |
| 44  | FX7221-Z | 3135687001  | BATTERY HOLDER                   | 1   |
| 45  | FX7221-Z | 3135688001  | BATTERY HOLDER                   | 1   |
| 46  | FX7221-Z | 5611270001  | Accessed Pan Head Flange Tapping | 6   |
| 47  | FX7221-Z | 3423696001  | UNDERCARRIAGE BRACKET            | 2   |
| 48  | FX7221-Z | 3580000029  | Bushing                          | 2   |
| 49  | FX7221-Z | 3709549001  | SUPPORTING PLATE                 | 2   |
| 50  | FX7221-Z | 5610361197  | Lock screw                       | 4   |
| 51  | FX7221-Z | 3800156004  | FABRIC                           | 1   |
| 52  | FX7221-Z | 5650710083  | Plain washer                     | 8   |
| 53  | FX7221-Z | 5650710136  | WASHER                           | 2   |
| 54  | FX7221-Z | 3580000030  | Stop plate                       | 3   |
| 55  | FX7221-Z | 5610361188  | Pan head screw                   | 3   |
| 56  | FX7221-Z | 3130253258  | STOP PLATE                       | 1   |
| 57  | FX7221-Z | 5610361170  | Hex screw                        | 2   |
| 58  | FX7221-Z | 3135689001  | RIGHT FEET COVER - FRONT         | 2   |
| 59  | FX7221-Z | 3135690001  | RIGHT FEET COVER - REAR          | 2   |
| 60  | FX7221-Z | 3135691001  | LEFT FEET COVER - FRONT          | 2   |
| 61  | FX7221-Z | 3135692001  | LEFT FEET COVER - REAR           | 2   |

|     |          |            |                                 |    |
|-----|----------|------------|---------------------------------|----|
| 62  | FX7221-Z | 3135693001 | FEET                            | 4  |
| 63  | FX7221-Z | 3135694001 | FRONT FRAME COVER               | 2  |
| 64  | FX7221-Z | 3135695001 | REAR FRAME COVER                | 2  |
| 65  | FX7221-Z | 5611254001 | PLASTIC SELF-TAPPING SCREW      | 16 |
| 66  | FX7221-Z | 3130253237 | Tapping screw                   | 8  |
| 67  | FX7221-Z | 3135698001 | MITER GAGE STORAGE              | 1  |
| 68  | FX7221-Z | 3709551001 | MITER GAGE STOP PLATE           | 1  |
| 69  | FX7221-Z | 5610361194 | Hex screw                       | 4  |
| 70  | FX7221-Z | 5640322018 | Clamping bolt                   | 2  |
| 71  | FX7221-Z | 5650710086 | WASHER                          | 2  |
| 72  | FX7221-Z | 3135700001 | FRAME PANEL SHEET               | 1  |
| 73  | FX7221-Z | 3135701001 | LOGO PANEL                      | 1  |
| 74  | FX7221-Z | 3709552001 | ANGEL HOLDING PLATE             | 1  |
| 75  | FX7221-Z | 3135702001 | PUSH STICK STORAGE              | 1  |
| 76  | FX7221-Z | 2851008001 | BATTERY INDICATOR               | 1  |
| 77  | FX7221-Z | 3135703001 | BATTERY INDICATOR COVER         | 1  |
| 78  | FX7221-Z | 3130253235 | Cam                             | 2  |
| 79  | FX7221-Z | 5650710087 | Toothed lock washer             | 2  |
| 80  | FX7221-Z | 5610361173 | Pan head screw                  | 3  |
| 81  | FX7221-Z | 5611269001 | ss Recessed Pan Head Tapping Sc | 7  |
| 82  | FX7221-Z | 5611268001 | ss Recessed Pan Head Tapping Sc | 7  |
| 83  | FX7221-Z | 5650710096 | WASHER                          | 2  |
| 84  | FX7221-Z | 3580000031 | Bushing                         | 1  |
| 85  | FX7221-Z | 3135704001 | BEVEL LOCK HANDLE               | 1  |
| 86  | FX7221-Z | 3660753046 | Compression spring              | 1  |
| 87  | FX7221-Z | 5650710088 | Plain washer                    | 2  |
| 88  | FX7221-Z | 5610361177 | Special screw                   | 1  |
| 89  | FX7221-Z | 5650710091 | Toothed lock washer             | 1  |
| 90  | FX7221-Z | 3709553001 | BEVEL POINTER                   | 1  |
| 91  | FX7221-Z | 3135706001 | BATTERY HOLDER - RIGHT          | 1  |
| 92  | FX7221-Z | 5610361214 | Tapping Screw                   | 4  |
| 93  | FX7221-Z | 3135707001 | BATTERY HOLDER - LEFT           | 1  |
| 94  | FX7221-Z | 5611274001 | ss Recessed Pan Head Tapping Sc | 4  |
| 95  | FX7221-Z | 3135708001 | POWER CORD COVER                | 1  |
| 96  | FX7221-Z | 5610361179 | Tapping screw                   | 4  |
| 97  | FX7221-Z | 3135709001 | BATTERY COVER HOLDER            | 1  |
| 98  | FX7221-Z | 5610361250 | Screw                           | 6  |
| 99  | FX7221-Z | 3135752001 | BUFFLE                          | 1  |
| 100 | FX7221-Z | 5611274001 | ss Recessed Pan Head Tapping Sc | 4  |
| 102 | FX7221-Z | 3580622001 | CLAMPING FLANGE                 | 2  |
| 103 | FX7221-Z | 5630352031 | Flange nut                      | 1  |
| 104 | FX7221-Z | 3135713001 | COVER                           | 1  |
| 105 | FX7221-Z | 5680258016 | KEY                             | 1  |
| 106 | FX7221-Z | 5630352032 | Wing nut                        | 1  |
| 107 | FX7221-Z | 3130253245 | Cover                           | 1  |
| 108 | FX7221-Z | 5680258017 | SOCKET WRENCH                   | 1  |
| 109 | FX7221-Z | 3130253246 | Cable clip                      | 1  |
| 110 | FX7221-Z | 5610361180 | Pan head screw                  | 4  |
| 111 | FX7221-Z | 3130253247 | GUARD PLATE                     | 1  |
| 112 | FX7221-Z | 3668028001 | TORSION SPRING                  | 1  |
| 113 | FX7221-Z | 3130253248 | Fixing plate                    | 2  |
| 114 | FX7221-Z | 3130253250 | Workpiece pusher                | 1  |
| 115 | FX7221-Z | 3130253260 | DUST ELBOW                      | 1  |
| 116 | FX7221-Z | 5610361182 | Hex screw                       | 2  |
| 117 | FX7221-Z | 2826622139 | SPRING PLATE                    | 1  |
| 121 | FX7221-Z | 5610346001 | Thread Forming Screw            | 4  |
| 122 | FX7221-Z | 3521052001 | Cover                           | 1  |
| 123 | FX7221-Z | 2850480001 | Spindle Assembly                | 1  |
| 124 | FX7221-Z | 2850863001 | Gear Case Assembly              | 1  |
| 125 | FX7221-Z | 2751627001 | Rotor Assembly                  | 1  |
| 126 | FX7221-Z | 3700249001 | Washer                          | 1  |

|     |          |            |                                  |   |
|-----|----------|------------|----------------------------------|---|
| 127 | FX7221-Z | 3121049001 | Rubber Spring                    | 1 |
| 128 | FX7221-Z | 2850864001 | Stator and Electronic Components | 1 |
| 129 | FX7221-Z | 5650013001 | Plain Washer                     | 4 |
| 130 | FX7221-Z | 5620472001 | Screw With Washer                | 4 |
| 131 | FX7221-Z | 2831629001 | Switch Electric Assembly         | 1 |
| 201 | FX7221-Z | 2850966001 | TABLE ASSEMBLY                   | 1 |
| 202 | FX7221-Z | 2850970001 | Clamping rod ASSEMBLY            | 1 |
| 203 | FX7221-Z | 2850972001 | RAIL PLATE ASSEMBLY              | 1 |
| 204 | FX7221-Z | 2850973001 | Front rail ASSEMBLY              | 1 |
| 205 | FX7221-Z | 2850974001 | Rear rail ass'y                  | 1 |
| 206 | FX7221-Z | 2850975001 | ROTATION Wheel ASSEMBLY          | 1 |
| 207 | FX7221-Z | 2850994001 | ELEVATION ROD ASS'Y              | 1 |
| 208 | FX7221-Z | 2850995001 | DRIVE ROD ASS'Y                  | 1 |
| 209 | FX7221-Z | 2850996001 | BASE FREME ASS'Y                 | 1 |
| 210 | FX7221-Z | 2850997001 | LADE GUARD STORAGE ASSEMBLY      | 1 |
| 211 | FX7221-Z | 2851000001 | FRAME PANEL ASSEMBLY             | 1 |
| 212 | FX7221-Z | 2851009001 | WHEEL ASSEMBLY                   | 1 |
| 213 | FX7221-Z | 4871044001 | Switch Assembly                  | 1 |
| 214 | FX7221-Z | 2851010001 | RIVING KNIFE ASSEMBLY            | 1 |
| 215 | FX7221-Z | 2851083001 | TABLE INSERT ASS'Y               | 1 |
| 216 | FX7221-Z | 2850976001 | RIP FENCE ASS'Y                  | 1 |
| 217 | FX7221-Z | 2850977001 | MITRE GAUGE ASS'Y                | 1 |
| 218 | FX7221-Z | 2851055001 | BLADE GUARD ASS'Y                | 1 |
| 219 | FX7221-Z | 2851012001 | ANTI KICK-BACK PAWL ASS'Y        | 1 |